



Detector DALI, Master, 41-750, 41-751, 41-760, 41-761, 41-780, 41-781, 41-784 and 41-785

Valid for software version 9 - [See versionsno.](#)

Use

The 360° DALI master detector consists of a single unit containing a control unit for DALI devices in up to three daylight zones with dimming as a function of incident daylight and up to two secondary zones for On/Off or dimming depending on the configuration.

The detector is designed for indoor installation and has a built-in light sensor and IR receiver for use in offices, schools and government buildings. The detector is suitable for both large and small areas.

The detector has a built-in relay for controlling either lighting or ventilation.

Communication on the DALI bus follows the DALI addressable principle, EN/IEC 62386-101/102.

A maximum of 64 DALI Control Gear can be connected to the detector. A push-button power switch is connected directly to the detector.

The detector has a built-in DALI power supply, which must not be connected to the external DALI power supply, nor may several master detectors be connected in parallel, as this will destroy both the DALI ballasts and the detector.

The detector can be integrated into solutions with DALI system components for overriding zones, either with DALI potentiometers, Niko-Servodan PMU-DALI, type 74-597 or DALI switch, Niko-Servodan DCP-4/B1, type 70-020. The 360 ° detection range can be divided into three sectors, A – B – C, each covering 120°. Sensitivity can be adjusted either collectively for all sectors or individually for each sector. Sectors can be isolated completely.

[Fig.2](#)

Programming and changes to settings are performed by IR remote control type 41-934 (accessory) or by the Niko Sensor Tool app and belonging IR-dongle type 41-936 (accessory). Simple overrides can be performed using the IR user remote (41-935, accessory), such as on/off and dimming, either for all zones at the same time or for each zone individually.

Typenr.	41-750	41-751	41-760	41-761	41-780	41-781	41-784	41-785
Flush mounted Fig. 3	•		•		•		•	
Surface mounted Fig. 4		•		•		•		•
Ceiling height 2-3,4 m	•	•			•	•		
High ceiling 4-8 m			•	•			•	•
Wireless EnOcean					•	•	•	•
Secondary detector 41-752/753	•	•			•	•		
Secondary detector 41-762/763			•	•			•	•

Guideline

The following guideline can be used for quick detector setup:

1. Position the detector. [Fig. 1.](#)
2. Connect the detector according to the circuit diagram. The detector is now in the "Out-of-the-box" mode. [Fig. 8.](#)
3. Test the installation for any errors or missing luminaires.
4. Initialise all DALI devices and divide the luminaires into zones. [Fig. 1.1.](#)
Note: Now the detector operates according to factory settings
If this is required - go directly to step 13
For other settings continue with step 5-13
5. Select mode. [Fig. 2.1.](#)
6. Program the required function: Automatic On/Off or Active On/Off with automatic off via the detector for the individual zones. [Fig. 3.2.](#)
7. Select the number of daylight zones, 2 or 3. [Fig. 1.2.](#)
8. Choose whether the daylight zones are to remain at the minimum level or if they are to turn off in case of over illumination. [Fig. 9.1.](#)
9. Set the required lux level for the daylight zones. [Fig. 4.1.](#)
10. Set the maximum lux output for the lighting system. See documentation for the lighting system or measure with a lux meter. [Fig. 4.7.](#)
11. Configure times. [Fig. 7/Fig. 5.1-5.4.](#)
12. The detector makes a fine-calibration of the lux-setting based on the room reflectance, when the lux level is 100 lux and nobody is in the room (typically at night). It may in certain cases be necessary to fine tune using a lux meter. [Fig. 4.15.](#) This can only be performed after the detector has performed fine-calibration. [Fig. 10.2.](#)
13. Enable a "Burn-in". Applies to fluorescent tube lights only. [Fig. 9.3.](#)

Installation

Location:

The detector responds to movement and heat in relation to the surroundings. Avoid placing the detector close to heat sources such as cookers, electric radiators or ventilation systems, or moving objects such as hanging mobiles etc. This may cause unintended activation. [Fig. 1.](#)

Installation height - typeno. 41-750, 41-751, 41-780 and 41-781:

The recommended installation height for this detector is 2 – 3.4 m. 2.5 m is the ideal installation height. At this height, the detector has a range of Ø20 m on ground level and Ø13.5 m at 80 cm table height (without lens cover).

Fig. 5.

Installation height - typeno. 41-760, 41-761, 41-784 and 41-785:

The recommended installation height for this detector is 4 – 8 m. At this height, the detector has a range of Ø16-32 m on ground level (without lens cover). **Fig. 6.**

Extending the detection area:

It is possible to increase the detection area by using a secondary presence detector, typeno 41-752, 41-753, 41-762 and 41-763. It is possible to connect ten secondary detectors to a master detector.

Note: The maximum power consumption must not be exceeded, and this is why a lower number of secondaryies is possible. **See planning.**

To achieve complete detection when using several detectors, it is recommended to calculate with an overlap of approximately 30 %.

Fig. 5 & 6.

Daylight zones:

Zone 1 always covers the fittings closest to incident daylight (the window), zone 2 covers the fittings in the middle of the room and zone 3 covers the fittings farthest away from incident daylight.

Connection:

The detector must not be connected to a power supply until all cable connections have been connected. After connection to the power supply, the detector will be ready to operate after approximately 40 sec. (warm-up time). Connect the detector according to the circuit diagrams. **Fig. 8.**

Connection of DALI control components:

DALI components for light override are connected directly to the DALI bus, e.g. potentiometer, Niko-Servodan PMU-DALI, type 74-597 or DALI switch, Niko-Servodan DCP-4/BI, type 70-020 for override of daylight zones 1 and 2, as well as secondary zone 3 or 4.

To control the light correctly, the DALI switches and potentio-meters must be configured for the zone (group) required.

The daylight zones: Configured as Group 10 for push buttons or potentiometer, which has the same function as push button 1 + 2.

Secondary Zone 3: Configured as Group 11 for push buttons or potentiometer, which has the same function as push button 3.

Secondary Zone 4: Configured for Group 12 for push buttons or potentiometer, which has the same function as push button 4.

As many push buttons as required can be connected. Remember that the maximum current of 200 mA must not be exceeded. It is possible to have multiple switches or potentiometers for the same function, such as for overriding zone 4. **Table 2.**

"Out-of-the-box" function:

Once the detector has been connected to the power supply and before the detector has initialised the DALI devices, all connected fittings will illuminate and the detector will function as an On/Off detector for all connected fittings. Off delay time is 15 min.

It is possible to switch all luminaires on and off manually via the connected 230 V push buttons or via the IR remote control type 41-934 (accessory) or by the Niko Sensor Tool app and belonging IR-dongle type 41-936 (accessory). All 230 V push buttons have the same function.

All LEDs (red, blue, yellow, green) will flash alternately to indicate that the detector has not been configured with the DALI setup.

Settings

Factory setting::

App.:	Mode 2, Daylight control and relay output for light On/Off.
Function:	Automatic on/off via detector
Zones:	2 daylight zones and 2 secondary zone
Lux:	300 lux
Time 1 (Off delay):	15 minutes Fig. 7.
Time 2 (HVAC):	30 minutes
Time 3 (Standby min.):	60 minutes
Time 4 (Orientation light):	10 minutes
Min/Off:	Minimum, daylight zones remain at minimum level in case of over-illumination.
Sensitivity:	High sensitivity, all sectors

Modes:

The presence detector can be set up in the following modes:

- Mode 1: Daylight control of up to three zones with relay output for HVAC
- Mode 2: Daylight control of up to three zones with relay output for light, On/Off
- Mode 3: Daylight control of up to three zones with relay output for Standby min.
- Mode 4: Daylight control of up to three zones with day/night light and relay output for HVAC

Get more functions by using the Niko Sensor Tool app.

Accessories

IR-dongle	41-936
IR remote control	41-934
IR user remote.....	41-935
Fittingring	41-990

Remote control

Programming functions using IR remote control tyep 41-934 (accessory).

See the guideline for programming. **Fig. 10.**

The detector must be unlocked for setting all configurations except "Status", "1", "2", "3", "4", "On/Off", "Auto", "Dim +" and "Dim -". The detector locks automatically after five minutes, if this is not done manually after the last time a button is activated. Any changes to settings will be saved. During programming, the green LED briefly switches off to acknowledge the correct receipt of information when a button is pushed on the IR remote control type 41-934 (accessory).

Operation & maintenance

Dirt affects the operation of the detector and the detector's lens must therefore be kept clean. Use a damp cloth for cleaning. Use water mixed with ordinary detergent. Avoid pressing hard on the lens. If the lens or other parts of the detector are defective, it/they must be replaced.

Technical data

Input:

Supply voltage..... 230 V AC $\pm 10\%$, 50 Hz
 Power consumption..... 0,45 W

Output:

Relay, dry contact..... μ 10 A, 250/400 V AC, NO
 Max. compensation capacity..... 140 μ F
 Max. starting current..... 165 A/20 m sec.
 800 A/200 μ sec.
 DALI..... 1-64 devices
 13 V DC/200 mA
 Secondary detectors up to 10 pcs.

Load:

Incandescent and halogen lamps..... 2300 W cos $\varphi = 1$
 Fluorescent tubes..... 1200 VA cos $\varphi \geq 0.5$
 Fluorescent tubes HF-ballast..... 1200 VA cos $\varphi \geq 0.9$
 Halogen electronic transformer..... 500 VA
 LED elektronic driver..... 500 VA
 LED lamps 230 V AC 350 W
 Energy-saving lamps, CLF..... 58 pcs. (18 W)

Performance:

Lux range..... 100 – 2.000 lux
 Time range (preset settings) 5 min. - ∞
 Detection area..... (3x120°) 360°
 Sensitivity 4 settings
 Protection class
 (gasket is mounted) IP 54
 Colour..... RAL 9010 (White)
 Ambient temperature..... -5°C ... +50°C

Performance typeno 41-750, 41-751, 41-780 and 41-781:

Detection range for body movement
 (at installation height of 3 m)..... 452 m²
 Range for small movements
 (at 2.5 m installation height)..... 9 m²
 Installation height..... 2 – 3,4 m

Performance typeno 41-760, 41-761, 41-784 and 41-785:

Detection range for body movement Ø16-32 m
 Installation height..... 4 – 8 m

Certifications:

CE in accordance with..... EN 60669-2-1

LED status

Overview of LED status: **Table 1.**

Status	Indication
"Out of the box"	All LEDs illuminate red, blue, yellow and green alternately. The detector is connected but not initialised.
Unlock	The green LED illuminates when the detector is in setting mode and is ready for configuration via IR remote type 41-934 (accessory).
Lock	The green LED switches off. The detector is locked and the most recently programmed changes are saved.
Initialisation	The red and green LEDs flash for 1 sec. On and 1 sec. Off during initialisation.
Zone allocation	When the correct zone is selected, the green LED will flash. If the wrong zone is selected, the green LED will switch off for one second and the red LED will illuminate for one second. When all units are addressed, the yellow LED will illuminate for one second.
Test mode sector A	The red LED will flash when activity is detected in sector A.
Test mode sector B	The green LED will flash when activity is detected in sector B.
Test mode sector C	The blue LED will flash when activity is detected in sector C.
IR remote control (accessory)	Each time the detector receives a correct signal from the IR remote control, the detector will acknowledge by briefly switching off the green LED if the detector is being programmed. In operating mode, the green LED will flash once.
Dim +	The green LED flashes for as long as the button is held down.
Dim -	The green LED flashes for as long as the button is held down.
8 hour For regulation of HVAC	The blue LED flashes for 1 sec. On and 1 sec. Off when the function is active and the detector is in operation mode.
Burn in	The yellow LED flashes for 1 sec. On and 1 sec. Off when the function is active.
Use the Niko Sensor Tool app and IR dongle to send configuration to the detector	The yellow LED flashes three times if the detector has not received a complete IR information package or if the detector does not understand IR information. This may be because the software in the detector is an older version.

Project planning

Power consumption:

The total power output that the detector can supply is 200 mA. This value must **NOT** be exceeded. This must be noted when installing DALI components.

Overview of typical power consumption: **Table 2.**

DALI component	Power consumption
DALI ballast	Max. 2 mA
Dimmer potentiometer PMU-DALI, type 74-597	Max. 6 mA
Presence detector, flush mounted, DALI secondary, type 41-752	Max. 5,5 mA
Presence detector, surface mounted, DALI secondary, type 41-753	Max. 5,5 mA
Motion detector, flush mounted, DALI secondary, 8 m High Ceiling, type 41-762	Max. 5,5 mA
Motion detector, surface mounted, DALI secondary, 8 m High Ceiling, type 41-763	Max. 5,5 mA
Inputmodule DCP-4/B1 DALI with 4 inputs, type 70-020	Max. 6 mA
DALI module DBC-1/TH for folding door and neighbouring zone control, type 70-021	Max. 14 mA

Ex. 1: The following components have been installed for lighting control in an office:

Quantity	Component	Power consumption	Total power consumption
48	Luminaires with 1 DALI ballast/luminaires	2 mA	96 mA
4	Dimmer potentiometer PMU-DALI, type 74-597	6 mA	24 mA
1	Input module DCP-4/B1 DALI with 4 inputs, type 70-020	6 mA	6 mA
			126 mA

Total power consumption for the connected DALI components is < 200 mA.

Ex. 2: The following components have been installed for lighting control in a conference room:

Quantity	Component	Power consumption	Total power consumption
56	Luminaires with 1 DALI ballast/luminaires	2 mA	112 mA
4	Input module DCP-4/B1 DALI with 4 inputs, type 70-020	6 mA	24 mA
1	Presence detector flush mounted DALI secondary type 41-752	5,5 mA	5,5 mA
1	DALI module DBC-1/TH for folding door and neighbouring zone control, type 70-021	14 mA	14 mA
			155,5 mA

Total power consumption for the connected DALI components is < 200 mA.

Glossary

Mode = Application, the way in which the detector will function.

Active On = The detector only switches on the light if the push button or potentiometer is activated, depending on the lux setting. The light switches off automatically after a preset time after the last registered activity.

Auto On/Off = The detector switches the light on automatically depending on the lux setting when activity is registered in the detection area. The light switches off automatically after a preset time after the last registered activity.





Constant On = Activation of Switch 1+2 (on > 10 sec.), light in the daylight zones is first adjusted to the maximum, flashes twice. The light switches on at the maximum and only switches off two hours + Time 1 (delay) after the last registered activity. The time is reset each time that activity is detected. The red LED illuminates in the detector to indicate active function. To cancel this function again, briefly activate Switch 1+2, the red LED in the detector will switch off. This function is intended for use during examinations.

Constant Off = Activation of Switch 1+2 (on > 10 sec.), light is first adjusted to the minimum, flashes twice. The light switches off and remains off, only switching on two hours + Time 1 (delay) after the last registered activity. The time is reset each time that activity is detected. The red LED illuminates in the detector to indicate active function. To cancel this function again, briefly activate Switch 1+2, the red LED in the detector will switch off.



Manuel override = Using a 230 V push button or DALI control parts, all zones can be controlled manually, either on/off or dimming. When manual override is active daylight control is deactivated.

Daylight control can be activated again in one of the following ways:




1. Press "Auto" on IR remote control type 41-934 (accessories) or IR user remote control type 41-935 (accessories).
2. Turn off and then turn the light on again on push buttons (Push button 1+2).
3. Wait until the expiry of the off delay time (Time 1) and orientation light time. (Time 4). **Fig. 7.**
4. By activating the "Auto" (scene 15), which is programmed on DCP-4 / BI, type 70-020 (accessories).

Fig. 1

Fig. 2

Fig. 3 - typeno. 41-750, 41-760, 41-780, 41-784





Gasket for IP 54



Lens cover

Fig. 4 - typeno. 41-751, 41-761, 41-781, 41-785


Lens cover

Fig. 5 - typeno. 41-750, 41-751, 41-780, 41-781

Fig. 6 - typeno. 41-760, 41-761, 41-784, 41-785

Fig. 7


Advarsel: Indbygning og montering af elektriske apparater må kun foretages af aut. elinstallatør. Ved fejl eller driftsforstyrrelser kontakt den aut. elinstallatør. Ret til ændringer forbeholdes!

Warning: Installation and assembly of electrical equipment must be carried out by qualified electricians. Contact a qualified electrician in case of fault or breakdown. Reserving the right to make changes!

Warnung: Einbau und Montage elektrischer Geräte dürfen nur durch Elektrofachkräfte erfolgen. Wenden Sie sich bei Störungen bzw. Ausfall an einen Elektrofach-kraft. Änderungen vorbehalten!

Avertissement: L'installation et le montage d'appareils électriques doivent exclusivement être exécutés par un électricien agréé. En cas de défaut ou de perturbation du fonctionnement, contacter un installateur électrique agréé. Sous réserve de modifications!

Varngd: Elektriska apparater får endast byggas in och monteras av en auktoriserad elinstallatör. Kontakta den auktoriserade elinstallatören vid fel eller driftstörningar. Med reservation för ändringar!

Advarsel: Innbygging og montering av elektriske apparater må kun utføres av autorisert elektriker. Autorisert elektriker skal også kontaktes ved fel eller driftsforstyrrelser. Det tas forbehold om endringer!

Fig. 8.1 - typeno. 41-750, 41-760, 41-780, 41-784





Fig. 8.2 - typeno. 41-751, 41-761, 41-781, 41-785





Fig. 9.1 Check software version via Niko Sensor Tool app




Fig. 9.2 Check software version via IR remote control






Fig. 9.3 Check software version on the detector part



PROGRAMMING	10
1. SELECT ZONE	
1.1 Initialization/Zone selection.....	10
1.2 Select 2 or 3 daylight zones	11
1.3 Program multi zone	12
1.4 Remove luminaires from multi zone	13
2. MODE	
2.1 Mode 1 Daylight control with HVAC output	14
2.2 Mode 2 Daylight control with relay/lighting (On/Off).....	14
2.3 Mode 3 Daylight control with relay for standby min.	14
2.4 Mode 4 Daylight control with day/night function	14
3. ECO SETTINGS	
3.1 Select Auto On/Active On (daylight zones).....	15
3.2 Select Auto On/Active On (secondary zone 3)	15
3.3 Select Auto On/Active On (secondary zone 4)	16
4. LUX	
4.1 Required lux level and max output, luminaires.....	17
4.2 Adjust lux level zone 1 (zone 2 and zone 3).....	17
4.3 Required lux level and max output, luminaires, 500 lux	17
4.4 Required lux level and max output, luminaires, 700 lux	17
4.5 Required lux level and max output, luminaires, 900 lux	18
4.6 Lux level 2000 lux and max output, luminaires.....	18
4.7 Max lux output, luminaires	18
4.8 Max lux output, luminaires, 500 lux.....	18
4.9 Max lux output, luminaires, 700 lux.....	19
4.10 Max lux output, luminaires, 900 lux.....	19
4.11 User dynamic lux setting, toogle	19
4.12 User dynamic lux setting, off	19
4.13 Program new daylight calibration	20
4.14 Reset daylight parameters to factory settings	20
4.15 Daylight factor, change to actual light conditions	20
5. TIME	
5.1 Time 1 – Off delay timer	21
5.2 Time 2 – HVAC timer	21
5.3 Time 3 – Standby minimisation timer	21
5.4 Time 4 – Orientation light timer	21
6. SENSITIVITY	
6.1 Select sensitivity, all sectors A, B and C	22
6.2 Select sensitivity, sector A (red).....	22
6.3 Select sensitivity, sector B (green).....	22
6.4 Select sensitivity, sector C (blue)	22
7. LIGHT SCENES	
7.1 Program light scene 1	23
7.2 Program light scene 2	24
7.3 Program light scene 3	26
7.4 Program light scene 4	27
8. WIRELESS - ONLY 41-780, 41-781, 41-784, 41-785	
8.1 Learn-in wireless push buttons (daylight zones).....	29
8.2 Learn-in wireless push buttons (sec. zone 3)	29
8.3 Learn-in wireless push buttons (sec. zone 4)	29
8.4 Delete learned-in push buttons (daylight zones).....	29
8.5 Delete learned-in push buttons (sec. zone 3).....	30
8.6 Delete learned-in push buttons (sec. zone 4)	30
9. OTHER OPTIONS	
9.1 Select Minimum or Off (daylight zones).....	31
9.2 Adjust minimum level orientation light, luminaires.....	31
9.3 Enable burn-in	31
10. SOFTWARE, ZONE, MODE, LUX	
10.1 Software version	36
10.2 Daylight calibration	36
10.3 Minimum or Off (daylight zones)	36
10.4 2/3 daylight zones	36
10.5 Zone 1	37
10.6 Zone 2	37
10.7 Zone 3	37
10.8 Zone 4	37
10.9 Automatic On/Active On (Zone 1)	38
10.10 Automatic On/Active On (Zone 2)	38
10.11 Automatic On/Active On (Zone 3)	38
10.12 Automatic On/Active On (Zone 4)	38
10.13 Mode	39
10.14 Lux level	39
10.15 User defined lux setting	39
11. TIME, SENSITIVITY, OTHER	
11.1 Time 1 – Off delay timer	40
11.2 Time 2 – HVAC timer	40
11.3 Time 3 – Standby minimisation timer	40
11.4 Time 4 – Orientation light timer	40
11.5 Sensitivity in sector A (red)	41
11.6 Sensitivity in sector B (green)	41
11.7 Sensitivity in sector C (blue)	41
12. OTHER OPTIONS	
12.1 Burn in	42
12.2 Constant HVAC output (8 hours)	42
13. OPERATION	
13.1 On/Off (All zones)	43
13.2 Dim up (All zones)	43
13.3 Dim down (All zones)	43
13.4 Daylight zones to daylight control	43
13.5 Luminaires On/Off (Zone 1)	44
13.6 Luminaires On/Off (Zone 2)	44
13.7 Luminaires On/Off (Zone 3)	44
13.8 Luminaires On/Off (Zone 4)	44
13.9 Dim up/down luminaires (Zone 1)	45
13.10 Dim up/down luminaires (Zone 2)	45
13.11 Dim up/down luminaires (Zone 3)	45
13.12 Dim up/down luminaires (Zone 4)	45
13.13 Light scene 1	46
13.14 Light scene 2	46
13.15 Light scene 3	46
13.16 Light scene 4	46



[Return to overview](#)

1.1 Initialization/Zone selection





[Return to overview](#)

1.2 Select 3 or 2 daylight zones




OR




[Return to overview](#)

1.3 Program multi zone




[Return to overview](#)

1.4 Remove luminaires from multi zone




[Return to overview](#)


2.1 Mode 1 - Daylight control with HVAC output




2.2 Mode 2 - Daylight control with relay for lighting (On/Off) - factory setting



2.3 Mode 3 - Daylight control with relay for Standby minimisation




2.4 Mode 4 - Daylight control with day/night function




[Return to overview](#)

3.1 Select between Auto On or Active On (daylight zones)




3.2 Select between Auto On or Active On (Secondary zone 3)




[Return to overview](#)

3.3 Select between Auto On or Active On (Secondary zone 4)




[Return to overview](#)


4.1 Required lux level and max output, luminaires: (See also step 4.7 "Max lux output, luminaires")




4.2 Adjust lux level zone 1 (zone 2 and zone 3)



4.3 Required lux level and max output, luminaires, 500 lux (See also step 4.7 "Max lux output, luminaires")



**FROM
SOFTWARE
VERSION 6**

4.4 Required lux level and max output, luminaires, 700 lux (See also step 4.7 "Max lux output, luminaires")



**FROM
SOFTWARE
VERSION 6**

[Return to overview](#)

4.5 Required lux level and max output, luminaires, 900 lux (See also step 4.7 "Max lux output, luminaires")


 FROM
SOFTWARE
VERSION 6


4.6 Lux level 2000 and max output, luminaires




4.7 Max lux output, luminaires (Step 4.1 must be done first)

Only if the luminaires are capable of giving more light than the required light level.



4.8 Max lux output, luminaires, 500 lux (Step 4.1 must be done first)


Only if the luminaires are capable of giving more light than the required light level.

 FROM
SOFTWARE
VERSION 6


[Return to overview](#)


4.9 Max lux output, luminaires, 700 lux (Step 4.1 must be done first)

Only if the luminaires are capable of giving more than the required light level.


 FROM
SOFTWARE
VERSION 6


4.10 Max lux output, luminaires, 900 lux (Step 4.1 must be done first)


Only if the luminaires are capable of giving more than the required light level.

 FROM
SOFTWARE
VERSION 6


4.11 User dynamic lux setting, toggle


 FROM
SOFTWARE
VERSION 6


4.12 User dynamic lux setting, Off


 FROM
SOFTWARE
VERSION 6


[Return to overview](#)


4.13 Program new daylight calibration



4.14 Reset daylight parameters to factory settings




4.15 Daylight factor, change to actual light conditions (Step 4.1 must be done first)




[Return to overview](#)


5.1 Time 1 - Off delay timer




5.2 Time 2 - HVAC timer



5.3 Time 3 - Standby minimisation timer




5.4 Time 4 - Orientation light timer




[Return to overview](#)


6.1 Select sensitivity (all sectors - A, B and C)




6.2 Select sensitivity in sector A (red)



6.3 Select sensitivity in sector B (green)




6.4 Select sensitivity in sector C (blue)




[Return to overview](#)

7.1 Program light scene 1




[Return to overview](#)

7.1 Program light scene 1




7.2 Program light scene 2





[Return to overview](#)




7.2 Program light scene 2





OR





OR






OR





OR






OR



OR




OR




[Return to overview](#)

7.3 Program light scene 3




[Return to overview](#)

7.3 Program light scene 3




7.4 Program light scene 4





[Return to overview](#)



7.4 Program light scene 4





OR





OR




OR





OR






OR



OR




OR




[Return to overview](#)


8.1 Learn-in wireless push buttons (daylight zones) - only valid for 41-780, 41-781, 41-784 and 41-785




8.2 Learn-in wireless push buttons (secondary zone 3) - only valid for 41-780, 41-781, 41-784 and 41-785



8.3 Learn-in wireless push buttons (secondary zone 4) - only valid for 41-780, 41-781, 41-784 and 41-785




8.4 Delete learned-in wireless push buttons (daylight zones) - only valid for 41-780, 41-781, 41-784 and 41-785




[Return to overview](#)

8.5 Delete learned-in wireless push buttons (secondary zone 3) - only valid for 41-780, 41-781, 41-784 and 41-785




8.6 Delete learned-in wireless push buttons (secondary zone 4) - only valid for 41-780, 41-781, 41-784 and 41-785




[Return to overview](#)


9.1 Select Minimum or Off, daylight zones



9.2 Adjust minimum level orientation light, luminaires




9.3 Enable burn-in




[Return to overview](#)


9.4 Disable burn-in




9.5 Enable constant HVAC output (8 hours)



9.6 Disable constant HVAC output




9.7 Walk test










[Return to overview](#)

9.8 Reset to factory settings




9.9 Add luminaires

Zone 4 - New luminaires




[Return to overview](#)

9.10 Non presence light level (Mode 4)




9.11 Presence light level (Mode 4)



[Return to overview](#)


9.12 External DALI Control Devices

FROM
SOFTWARE
VERSION 8




[Return to overview](#)


10.1 Status - software version

 FROM
SOFTWARE
VERSION 6



10.2 Status - daylight calibration

 FROM
SOFTWARE
VERSION 6


10.3 Status - Minimum or Off, daylight zones




10.4 Status - 2/3 daylight zones




[Return to overview](#)


10.5 Status - Zone 1




10.6 Status - Zone 2



10.7 Status - Zone 3




10.8 Status - Zone 4




[Return to overview](#)


10.9 Status - Automatic On or Active On (Zone 1)




10.10 Status - Automatic On or Active On (Zone 2)



10.11 Status - Automatic On or Active On (Zone 3)




10.12 Status - Automatic On or Active On (Zone 4)




[Return to overview](#)


10.13 Status - Mode



10.14 Status - Lux level




10.15 Status - User dynamic lux setting


 FROM
SOFTWARE
VERSION 6


[Return to overview](#)


11.1 Status time 1 - Off delay timer




11.2 Status time 2 - HVAC timer



11.3 Status time 3 - standby minimisation timer




11.4 Status time 4 - Orientation light timer




[Return to overview](#)


11.5 Status - Sensitivity in sector A (red)



11.6 Status - Sensitivity in sector B (green)




11.7 Status - Sensitivity in sector C (blue)




[Return to overview](#)

12.1 Status - Burn in




12.2 Status - Constant HVAC output (8 hours)




[Return to overview](#)


13.1 Operation - On/Off (All zones)




13.2 Operation Dim up (All zones)



13.3 Operation Dim down (All zones)




13.4 Operation - Daylight zones to daylight control




[Return to overview](#)


13.5 Operation - Luminaires On/Off (Zone 1)




13.6 Operation - Luminaires On/Off (Zone 2)



13.7 Operation - Luminaires On/Off (Zone 3)




13.8 Operation - Luminaires On/Off (Zone 4)




[Return to overview](#)


13.9 Operation - Dim up/down luminaires (Zone 1)




13.10 Operation - Dim up/down luminaires (Zone 2)



13.11 Operation - Dim up/down luminaires (Zone 3)




13.12 Operation - Dim up/down luminaires (Zone 4)




[Return to overview](#)


13.13 Operation - Light scene 1



13.14 Operation - Light scene 2



13.15 Operation - Light scene 3



13.16 Operation - Light scene 4

