

Double key with 'I' and 'O' symbols for push button with 4 control buttons and 4 feedback LEDs

121-00034

4 års
garanti

Double key for a bus push button with 4 control buttons and 4 feedback LEDs. The key is printed with the symbols "I" and "O". Farve: sterling.

Tekniske data

Double key with 'I' and 'O' symbols for push button with 4 control buttons and 4 feedback LEDs.

- Funktion: Tangent til en Nikobus-trykknop eller en RF-vægsender.
- Antal betjeningstryk: 2 kontrolknapper
- Materiale centralplade: Centralpladen er emaileret og fremstillet af hård PC og ASA.
- Farve: enamelled sterling
- Udskrift: På hver tast på centralpladen er symbolerne "I" og "O" præget permanent.
- Linse: De to knapper på centralpladen er udstyret med 2 rektangulære, transparente linser.
- Demontering: For at afmontere skal du blot trække centralpladen af mekanismen.
- Kapslingsklasse: IP41 for kombinationen af en mekanisme, centralplade og en forsænket surroundplade
- Vandalklasse: Efter montering garanteres en slagfasthed på IK06.
- Brandsikkerhed
 - Centralpladens plasticdele er selvslukkende (overholder en glødetrådtest på 650 °C)
 - Centralpladens plasticdele er halogenfri.
- Dimensioner på færdiggørelse: 45 x 45 mm (HxW)
- Godkendelse: CE

